

Split-type heat pump



Wi-Fi module manual

As a result of continuous product development, the manufacturer reserves the right to make changes to the products and technical documentation for the devices.

The installation should be carried out by qualified personnel. To ensure a trouble-free installation, please familiarize yourself with this manual and follow the information provided within it. Please keep this manual for future reference. The controller is intended for use with the ECOs HEAT unit.

Part1 Download and install the control software

The control software can be downloaded and installed as follows.

 For mobile terminals such as smart phones and tablet (Android 4.1 and IOS 6.0 or above only), search and download "AC Freedom" from Google Play or App store on and install it on your system.
 You may also use your mobile terminal (Android 4.1 and iOS 60 or above only) to scan the "QR code" with a third party scan tool, which will automatically direct you to the download interface of AC Freedom for you to download and install the software.



For Android




ENG

ENG

For iOS


Once the control software is installed, enter the "Scanning Interface (for downloading the Welcome Page). There are two types of log-on contained in the Scanning Interface:



2

3

1. By clicking "scan" and scanning the QR code on the right.



Part 2: Reset WI-FI module

In the case of first time configuration or after changing the connected wireless router is, the WI-FI module inside the heat pump needs to be reset.

To reset the module:

ENG

ENG


Press "OPTIONS" in the "Menu" of the wired controller, select "WLAN CONFIG" and confirm, and confirm again after a pop-up window appears. After the reset is successful, the icon "" in the upper right corner blinks.

MENU	OPTIONS
DOMESTIC HOT WATER(DHW)	HOLIDAY HOME
OPTIONS	FLOOR PR NOT DETECTED
BOOKING AND SCHEDULE	FLOOR DR WLAN MODULE
HIM CONFIG	AUTO RELO OK
STATE CHECK	WLAN CONFIG
OK V∧ <> BACK	V A <> BAC

ΟΡΤΙΟ	NS			2022-12-2	21	10:00	TUE 🖗
HOLIDAY	IOME		-	OFF	ı	13c	OFF
FLOOR PI	RESTORE WLAN?						10
FLOOR D					-6-	25°	
AUTO RE	NO	yes		2	,	×	20
WLAN CO	NFIG						
	٧A	< >	BACK	MENU			

Part 3: Add device

A. Connect the mobile phone to the wireless network, open the APP, click "Add Device", select "Heat Pump", and start adding;



6

B. Connect the mobile phone WLAN to "AC-xxxx" (xxxx consists of letters and numbers, which are randomly generated), and return to the APP

ENG

ENG

Cancel	←		
Connect your phone to the device	WLAN		
Go to your Wi-Fi settings and select the Wi-Fi ssid of device which name like "AC_XXXX" The last four bits are MAC addressed	wLAN		
Return after the network is connected.	WLAN	>	
	🗢 Home WiFi	• 0	
		a >	
Settings	(^{In})		
Can't find the device network? (

7

C. Enter the wireless network password and click "Connect to Wi-Fi" (Android and IOS phones have different operation sequences in steps B and C, the specific situation is subject to the APP display)

Commenting to "Ula				
Connecting to Ho	Connecting to "Home WiFi"			
 Sending Wi-Fi SSID at device 	nd password to the			
Please make sure the to "Home WiFi". Ta	evice is connecting to the Wi-Fi make sure the phone is connected ome WiFi". Tap connect to go to Wi-Fi settings and re-connect it.			
Cancel	Connect			
	qui			
	 The device is connect Please make sure the to "Home WiFi". Ta your WI-Fi settings 			



ENG

ENG

Note: If the configuration fails or you change the password of wireless router, you need to reset the WIFI module to reconnect: repeat the steps above for APP configuration.

8

9

Part 4: Others

- 1. The software provides help service through which the users may check the operational instructions of the software and other information.
- 2. Besides, as the operation interface and the function of the software is under constant improvement, we will keep you informed about the subsequent upgrades for your updating.
- 3. As the operation interface may change due to the constant version upgrading the figures in this manual are for reference only, so please rely on the actual operation interface.





ENG

Exclusive importer of the SEVRA brand: WIENKRA Sp. z o. o.

⊕www.wienkra.pl ⊕www.sevra.pl

 Kraków:
 Warszawa - Janki:

 Q ul. Kotlarska 34, 31-539 Kraków
 Q ul. Sokołowska 15, 05-090 V

 Q ul. Rzemieślnicza 20G, 30-347 Kraków
 Swienkra-waw@wienkra.pl

 Warszawa - Janki:
 Wrocław:

 9 ul. Sokołowska 15, 05-090 Warszawa
 9 Al. Armii Krajowej 61, 50-541 Wrocław

 gwienkra-waw@wienkra.pl
 Swienkra-wro@wienkra.pl